北京阁科北记澈老拉卡有限公司

Millijoules high master-slave pulse ratio 532 nm picosecond laser

Zhao You

• Fan Zhongwei¹, Bai Zhenao¹², Zhang Guoxin², Lian Fuqiang¹², Zhao You³, Shen Ming³

2014-10

- 1 Academy of Opto-Electronics, Chinese Academy of Sciences, Beijing 100049, China
- 2 Beijing GK Laser Technology Co., Ltd., Beijing 100192, China

• 3 National Astronomical Observatories, Chinese Academy of Sciences, Beijing 100012



Introduction - Backgrounds

Applications of all-solid-state short pulse lasers:

- ✓ Material cutting & forming
- ✓ Micro processing
- ✓ Medical equipment
- ✓ Space exploration















Nanosecond

- Serious thermal effects
- High edge burr
- High etching width
- Can not meet the requirements of etching width

Picosecond

- Short action time
- Less edge burr
- Low price
- Easy maintenance
- Batch production
- Low production cost

Femtosecond

- Short action time
- Less edge burr
- High price
- Poor stability
- Complex structure
- High maintenance costs







V

Nano



Femto

Femtosecond laser processing

Picosecond laser processing

Nanosecond laser processing

Experimental Configuration — SESAM mode-locking



SESAM mode-locking results



Fig.1 Waveform of CW mode-locked pulses









Experimental Configuration



- MOI is a magneto optic isolator.
- PC is a BBO crystal Electro-Optical (EO) Pockels Cell.
- Nd:YAG rod is pumped with CW laser diodes.

Experimental Configuration



The LBO crystal is coated with 1064 nm AR coating on the incident surface and 532 & 1064 nm AR coated on the other surface. M9 is a beam splitting lens that is AR-coated at 1064 and HR-coated at 532 nm. Garbage is used to absorb the rest of infrared light.

Experimental Result



(a) Regenerative pulse sequence at 1 kHz



(b) single pulse

Experimental Result





Output beam profile for the amplified pulse

Autocorrelation curve of the output pulse

Experimental Result



Power stability measured in long term operation (22.4 hours)



picosecond laser system



Working state of system in SLR



Laser returns from the satellite

Summary

• We have developed a high master-slave pulse ratio 532 nm picosecond laser on the magnitude of millijoules.

• The system combines the techniques of SESAM passively mode-locking, regenerative amplifier, and LBO crystal frequency doubling.

• The output pulses of the system have good beam quality and high stability that in continuous operation for more than 22.4 hours without failure.

• Through the actual ranging, we draw the conclusion that this system is capable to be applied in SLR.

我们用激光雕塑未来

Acknowledgement

The authors gratefully acknowledge financial support by the funding from the National key foundation for exploring scientific instrument (No. 2011YQ120024)







• Founded in 2002.

• A high-tech enterprise under holding of Chinese Academy of Sciences (CAS).

Hi-tech Enterprise Certification by Beijing Municipal Science & Technology Commission in 2006.

- National Hi-tech Enterprise Certification in 2008.
- Hundreds of National Innovation Model innovative pilot enterprises in Zhongguancun in 2009.
- National Torching Plan Key High-Tech Enterprise in 2012.

 Beijing international science and technology cooperation base of advanced semiconductor pump laser technology (2014).

- The First Class Prize of Beijing Science and Technology Progress Award (Municipal)
- The Second Class Prize of National Science and Technology Progress Award (National).



• More than 1,200 square meters of clean workshop and with semiconductor laser production lines .

- Producing a variety of lasers is more than thousands of sets per year.
- We has a group of more than 40 researchers, including 11 senior professional titles, 13 doctors and 23 masters.
- 6 talents have been selected by Leading Talent of Scientific Beijing, New Science and Technology Star, The Excellent Talent of Beijing and Zhongguancun Leading Talent.





Beijing GK Laser Technology Co. Ltd.

Academy of Opto-Electronics (AOE) Chinese Academy of Sciences

- Optical engineering national key disciplines and disciplines.
- Postdoctoral working station and mobile station.
- Open project (The new technology of laser, materials research etc..)

Partial products of GK Laser Technology Co., Ltd.



Laser range findor

Laser cutting machine

Laser marking machine

Laser power supply

All-solid-state picosecond solutions



> The successful bid rate of our picosecond laser in the domestic is up to 30%.

> Our clients include Peking University, Zhejiang University, Shenzhen University, and Chinese National Astronomical Observatory of China Academy of Engineering Physics etc..

Partial picosecond products & parameters

| Wavelength (nm) | 1064 | | | |
|----------------------------------|-------------------|---------------------------|------------------------|--|
| Repetition Rate (kHz) | 10-500 | | | |
| Power (W) | 30 | | | |
| Energy (µJ) | 120 | | | |
| Beam Diameter (mm) | <3 | | | |
| Beam Specifications | | | | |
| Pulse Width (ps) | <20 | Polarization | Horizontal (or others) | |
| Spatial Mode | TEM ₀₀ | Divergence (mrad) | <5 | |
| M ² | <2 | Ellipticity | <15% | |
| Power Stability (RMS) | <3% | Pointing Stability (µrad) | <50 | |
| Cooling Method | Water | LD Lifetime | 10000h | |
| Dimensions Laser Head (mm) | 1020×560×220 | | | |
| Controller Size (U) | 8 | | | |
| Working Temperature($^{ m C}$) | 25±5 | | | |



| Wavelength(nm) | 1064/532 | | |
|---|---------------------------|-------------------|--|
| Repetition Rate(Hz) | 1-1000 | | |
| Products | 常规 | 高能量 | |
| Energy (mJ) | ≤2 | ≤30 | |
| Beam Diameter (mm) | <2 | <6 | |
| Pulse Width(ps) | <40ps@1064nm; <20ps@532nm | | |
| Spatial Mode | TEM ₀₀ | | |
| M ² | M ² <1.5 | M ² <6 | |
| Power Stability (RMS) | 3% | | |
| Polarization | Horizontal (or others) | | |
| Divergence (mrad) | <1mrad | | |
| Ellipticity | <15% | | |
| Pointing Stability (µrad) | <50 | | |
| LD Lifetime | 10000h | | |
| Dimensions Laser Head (mm) | 1000×290×110 | 1080×580×210 | |
| Controller Size (U) | 3 | 13 | |
| Working Temperature($^{\circ}\!\!\mathbb{C}$) | 25±5 | | |







http://www.gklaser.com/

Address: Changping District of Beijing, Baige Rode 9 yuan 1# floor on the second floor

地 址:北京市昌平区百葛路9号院1号楼二层

Telephone number: 010-56760700

Fax: 010-56760707

After-sales service: 010-56760730

Email: xxx





Thank you for your attention !

